


CONFIGURE THE INITIAL SETTINGS.



MENU 20

TEMPERATURE FORMAT (°F / °C)

MENU 30

HEATING MODE

Baseboard (OFF) / Fan Heater (ON)

MENU 31

LOBBY MODE*

Standard Room (STD) / Lobby (LbY)

*Lobby mode is an option only in Fan Heater mode.



INSTALL AND CONFIGURE THE ALLIA APP.







PAIR THE THERMOSTAT TO THE ALLIA ECOSYSTEM.

- **1 -** In the Allia application, click on the + in the device tab.
- **2 -** Select thermostat as device type.
- 3 On the thermostat, access menu 10 by pressing the central button for 3 seconds and select the automatic connection option (ON). Press the central button to confirm the selection.



Connection established.



°STELPRO



QUICK START GUIDE



BEFORE GETTING STARTED

Choosing the location of your devices wisely will optimize Allia's mesh network and promote efficient communication between the devices.


Leave at least 12 in. clearance around the thermostat to ensure adequate ventilation.

For more information, visit www.stelpro.com/en/allia

WARNING


- 1 To reduce the risk of fire, electric shock or electrocution, CUT OFF THE POWER AT THE ELECTRICAL PANEL and make sure the circuit is switched off.
- 2 Always follow the electrical code in effect in your region. The thermostat must be installed by a CERTIFIED ELECTRICIAN.
- **3 -** Connect the thermostat ONLY to a 120 VAC to 240 VAC power source and observe the load limits.

REMOVE THE OLD THERMOSTAT AND ATTACH THE MOUNTING PLATE TO THE ELECTRICAL BOX.



NOTE: Loosen the screw under the thermostat slightly to remove the mounting plate from the thermostat.

CONNECT THE ELECTRICAL WIRES.



For baseboards, convector and fan heaters

3 CONNECTORS UNIVERSAL CONNECTION

For baseboards and convectors only

3 CONNECTORS
ALTERNATIVE
CONNECTION

For baseboards and convectors only

2 CONNECTORS CONNECTION Visit our website to get more information, learn everything there is to know about Allia or view the complete user guide.

www.stelpro.com/en/allia

RYEAR







